Verifying "Phase Reversal" alarm

1) Press the "CONFIG" button (a menu will appear with 3 choices)

2) Press the "CONFIG" button (which has a 2 on it) to select menu choice 2 "USER PREFERENCES"

3) Using the up/down arrow keys scroll to 223 "Reversed phase".

4) Press the "CHANGE/ENTER" button.

5) If asked for a password press the "SYSTEM LOGS" button (which has a 1 on it) four times-password=1111

6) Use the up/down arrow keys to either change the NO to YES or vice versa.

7) Press the "CHANGE/ENTER" button, the alarm should sound within a minute or so.

8) Press the "SILENCE/LAMP TEST" button to silence the alarm horn.

9) After demonstrating the alarm function you will have to repeat this procedure to put the setting back the way it was to clear the alarm.

If you have any problems/questions give me a call at 985-351-5681.